

4-, 8- AND 12-CHANNEL PIPETTES

Tilletek

SPARE PART

The codes for some parts of a multichannel pipette depend on the number of channels and its volume. See exploded views below.

Fixed volume

Adjustable volume

When ordering the knob 105 0439
please give the volume of your pipette.

Calibration adjustment 105 0500

Top spring operator (black) 105 0520

Operator spring 113 0040

Bottom spring positioner 105 0580

Grippy 105 0590

When ordering the handle 220 1369
please give the volume of your pipette.

Tip release,
operator shaft 105 1330

Operator button piston
105 0720

Tip release spring 113 0110

Body assembly

220 0500 for 4-channel 5- 50 μ l
220 0510 for 4-channel 50-250 μ l
220 0520 for 8-channel 5- 50 μ l
220 0530 for 8-channel 50-250 μ l
220 0540 for 12-channel 5- 50 μ l
220 0550 for 12-channel 50-250 μ l

Tip release, operator plate
105 1580 for 4-channel
105 1590 for 8-channel
105 1600 for 12-channel

Screw 020 0000

Operator button 105 0001

Calibration adjustment 105 0501

Top spring operator
(yellow) 105 0530 for 5- 50 μ
(green) 105 0550 for 50-250 μ

Operator spring 113 0041

Grippy 105 0591

Handle 105 0691 for 5- 50 μ
Handle 105 0701 for 50-250 μ

Transparent ring 105 113

Locking ring 105 115

Body assembly

220 0560 for 4-channel 5- 50 μ
220 0570 for 4-channel 50-250 μ
220 0580 for 8-channel 5- 50 μ
220 0590 for 8-channel 50-250 μ
220 0600 for 12-channel 5- 50 μ
220 0610 for 12-channel 50-250 μ

Tip cone assembly

220 0090 for 4-channel, 5- 50 μ
220 0160 for 4-channel, 50-250 μ
220 0100 for 8-channel, 5- 50 μ
220 0170 for 8-channel, 50-250 μ
220 0110 for 12-channel, 5- 50 μ
220 0180 for 12-channel, 50-250 μ

Screw 020 0001